

# SafeWaste Multi-fit Lid Latch Installation Guide

## Step 1:

Before you start – Wetting the latch with water makes installation much easier!

## Step 2:

Hold the latch so that the hook is facing down, and slide it under the cart lid handle.



## Step 3:

Bring the rounded end (Pull Tab) of the latch over the top of the cart lid handle and push it through the buckle.



## Step 4:

Pull the latch hook and 'S-Flex' section completely through the buckle, using the guide below;

For cart sizes 180L/240L/360L: The latch should be firmly looped around the handle.



For cart sizes 80L/120L/140L: The latch should be loosely looped around the handle



## Step 5:

Holding the Pull Tab firmly, pull the latch down so the hook engages under the cart rim.  
Your bin lid is now securely fastened.  
To open the cart lid, pull the Tab out from the cart rim to dis-engage the hook.



## Step 6:

Check the tension on the 'S-Flex' by engaging the latch to secure the cart lid.  
If the 'S-Flex' is over-stretched (too much tension) OR if the hook is not properly engaged on the cart rim (too little tension), adjust the tension by tightening/loosening the loop around the handle. The 'S-Flex' should be similar to the the images below.



**NOTE : THE SAFEWASTE LATCH IS DESIGNED TO AUTO-RELEASE WHEN THE CART IS EMPTIED INTO THE RUBBISH/RECYCLE COLLECTION TRUCK.**

**PLEASE ENSURE THE CART LID IS SECURED WITH THE LATCH WHEN YOUR CART IS PLACED ROADSIDE READY FOR COLLECTION.**